

Limora Zentrallager
Industriepark Nord 21
D- 53567 Buchholz
Tel: 49 (0) 2683-9799 0
E-Mail: Limora@Limora.com
Internet: www.Limora.com

Filialen:
• Aachen • Berlin • Bielefeld
• Düsseldorf • Hamburg
• Köln • Stuttgart

Installation instructions

Rod Change Shifter Conversion Bracket

1. Bolt the bracket to the gear lever housing with the steeper angle on the cars right hand side and raise in to the approximate position to allow for the bobbin mounts. Transfer the bracket bolt hole locations on to the tunnel.
2. Lower the gear lever housing and drill the marked locations with an 8mm drill bit.
3. Install the mounts in to the bracket and mount the bracket and housing to the tunnel.
4. Check for clearance between the gear lever and hole in the tunnel throughout all gear selections.