



**Limora central warehouse**  
Industriepark Nord 21  
D - 53567 Buchholz  
Tel: 49 (0) 26 83 - 97 99 0  
E-Mail: [Limora@Limora.com](mailto:Limora@Limora.com)  
Internet: [Limora.com](http://Limora.com)

**Stores:**  
• Aachen • Berlin • Bielefeld  
• Düsseldorf • Hamburg  
• Köln • Stuttgart

## Dashboard Installation Instructions

**TOOLS REQUIRED:** Ammonia type window cleaner, clean rag, fine grit sandpaper, masking tape and a single edge razor blade.

### Cleaning and preparing your old dashboard

1. Prefit your new dashboard to make sure you have the correct model and fit.
2. If your dashboard is cracked or has high spots, use a razor blade or sandpaper to trim the raised areas.
3. Lightly sand the old dashboard and the underside of the new dashboard.
4. Thoroughly clean the old dashboard and the underside of the new dashboard, with ammonia type window cleaner. This should remove any oils or preservatives that have built up over the years.
5. Recheck the fit of your new dashboard by placing it over the clean dashboard. Old dashboards sometimes expand over the years, so you may have to do some trimming to achieve the best fit.
6. In some cases you might have to remove speaker grids and defroster vents.

### Installing the dashboard

1. After your dashboard fits properly, prepare the silicone adhesive. Place the tube of silicone adhesive in a cup of hot water. This will soften it and make it flow easier.
2. Apply the adhesive to the underside of the new dashboard around the perimeters of air vents, radio speaker openings, climate sensors and outer edge.
3. The adhesive „bead“ should be about the size of a pencil.
4. DO NOT put adhesive closer than 1/2" from the edge.
5. DO NOT put adhesive in the center of the dashboard, as it will not allow the dashboard to expand and contract in the hot and cold weather.
6. Remember less adhesive is better.
7. Place the dashboard over the original dash. You may need to wedge heavy objects between the dash and windshield, or use masking tape, cardboard wedges, or bungee cords to secure your dashboard.
8. It will take 2 to 4 hours for your adhesive to setup.